

Inside Mount Frosted White Fauxwood Blinds Installation Instructions

Congratulations on your purchase of 2.5" Timeless Cordless Faux wood Blinds! You've made a great choice that enhances your living area's beauty, offers excellent insulation, and may increase your home's value.

*Philips Bit OR 1/4" Nut Driver Required



Drill With 5/64" Bit



Flat- Head
Screwdriver



Pencil

Review Fauxwood Blind Components

1.



Blind

2.



Valance

3.



Wand

4.



Install Brackets

5.



Valance Clips

6.



Install Screws

A.



Align edge of mounting bracket with top corner of the window frame.

Step: 1 Install Brackets

C.



Using drill with 5/64" bit, predrill holes into the marks that were made.

B.



Mark two holes in the back upper and front lower spots.

Repeat Steps Right and Left side of the Blind

D.



Using phillips bit, hold mounting bracket in place and drill screws into the holes.

A.



Attach valance clips to headrail.

Step: 2 Install Headrail

E.



Pull blind down and Push up to ensure proper operation.

B.



Push doors closed until they snap to lock.

C.



Slide headrail with valance clips attached into the mounting brackets clicks.

D.



Attach wand

F.



If you need to remove your blind, remove valance and use Flat Head screwdriver to pop open brackets.

Contact Information:  **SelectBlinds.**

If you have any questions, please call us at (888) 257-1840.
For additional details and installation guidance, including videos, visit our website at www.selectblinds.com.



SelectBlinds®

Outside Mount Frosted White Fauxwood Blinds Installation Instructions

Congratulations on your purchase of 2.5" Timeless Cordless Faux wood Blinds! You've made a great choice that enhances your living area's beauty, offers excellent insulation, and may increase your home's value.

*Philips Bit OR 1/4" Nut Driver Required



Drill With 5/64" Bit



Flat- Head
Screwdriver



Pencil

Review Fauxwood Blind Components

1.



Blind

2.



Valance

3.



Wand

4.




Install Brackets

5.



Valance Clips

6.



Install Screws

A.



In the top left corner of your window, measure upward and mark somewhere between 2 and 4 inches above your window and repeat the same in the top right corner of the window.

Step: 1 Install Brackets

E.



Take left side bracket and center the top edge to your mark and use your pencil to mark the location of the holes for each screw.

Repeat these steps on the right side of the window with the right side bracket.

B.



Subtract the width of your window from the width of your blinds.

D.



Mark that distance out from your previous marks. Repeat on the other side.

F.



Using drill with 5/64" bit, predrill holes into the marks that were made.

C.



To determine how far out to put the brackets on each side so that they are centered over the window.

G.



Using a Philips bit, hold mounting bracket in place and drill screws into the holes.

Repeat these steps on the right side of the window with the right side bracket.

A.



Once brackets are in place, evenly attach valance clips to the headrail.

Step: 2 Install Headrail

F.



Attach valance.

B.



Slide headrail with valance clips attached into the mounting brackets.

D.



Attach wand

E.



Attach valance returns if needed.

G.



Pull blind down and bush up to ensure proper operation.

C.



Push doors closed until they snap to lock.

H.



If you need to remove your blind, remove valance and use Flat Head screwdriver to pop open brackets.

Contact Information: SelectBlinds.

If you have any questions, please call us at (888) 257-1840.
For additional details and installation guidance, including videos, visit our website at www.selectblinds.com.