


Vertical Blind – Wand Control Installation Instructions

Please follow these Installation Instructions

You will need a pencil, tape measure, drill, screwdriver, pliers, and appropriate fasteners.

Step 1: Choose the Correct Fastener



1 1/2" #8 Hex Head Wood Screws (Included)

Alternative fasteners should be used for aluminum or concrete installations (Not Included with Blinds)

Step 2: Bracket Installation

(Before installing, review the chart below to confirm the correct # of brackets per blind) For Inside Mount blinds with a valance Go to step 7


Outside Mount (Figure A)




Standard wall mount installation brackets are adjustable and provide 1/2" to 1 1/2" wall clearance. Determine the height for the top of the bracket (measured from the floor) by adding 1/2" to the blind height including the headrail. When installed, louvers will clear the floor by 1/2".

Place the first bracket directly over the corner of the window with a maximum space of 30" between brackets. Adjust the bracket so the louvers clear all obstructions.

Inside Mount No Valance (Figure B or C) Inside Mount with a Valance see step 7



Use mounting clips to secure headrail on ceiling or inside mounts. The center of the mounting clips align with the center of the louver carrier stem. Position the screws a minimum of 2 1/4" in front of the window frame or any projection. Set mounting clips with a maximum space of 30" apart from each other. Allow a minimum of 1/2" clearance above sill or carpet.




Use the following # of Installation Brackets based on the Blind Width:

Up to 54"	54 - 1/8" - 84"	84 1/8" - 108"	108 1/8" - 132"	132 1/8" - 156"	156 1/8" - 180"
2	3	4	5	6	7


Step 3: Headrail Installation

Mount the installation brackets on the headrail then snap in place, as shown below. To remove headrail, simply push the release lip up with a screwdriver.




Step 4: Louver Installation

Push the louver up into the carrier stem, then pull slightly straight down to lock in place.




Step 5: Test Rotation



To rotate the louvers, rotate the wand in the direction you want the louvers rotated. This step will align all of the louvers

Step 6: Test Traverse



Alternatively To traverse the louvers, rotate the louvers to the open position then push or pull the wand to open (stack louvers) or close (unstack louvers) the blind. **Caution: Do not traverse the blind with the louvers in the closed position.**


Vertical Blind– Wand Control Installation Instructions

Step 7: Valance Installation

For inside or ceiling mounts, install the headrail bracket clip mounting screw through the valance as shown. Make sure louvers do not touch the valance.


For outside mounts, the dustcover of the valance slides under the protruding clip on the top of the mounting brackets.

Inside Mount




Valance Clip

Outside Mount



Valance Returns

Valances are available with Square Snap in Corner Returns or Round Corner Returns. Returns for Round Corner Valances will come preassembled. For Square Corner Valance Returns, slide the clear plastic corner clip onto the top edge of the valance. Then slide the valance return into the other side of the corner clip as shown. Valance returns may be trimmed to fit if necessary with heavy duty scissors.



Operating Instructions

Wand Control To rotate the louvers, rotate the wand in the direction you want the louvers rotated. To traverse the louvers, rotate the louvers to the open position. Then, push or pull the wand to open (*stack louvers*) or close (*unstack louvers*) the blind. If louvers are installed with the front of the louver facing the wand, the wand will be in front of the louvers when the blind is rotated closed. If the louvers are installed with the back of the louver facing the wand, the wand will be in back of the louvers when the blind is rotated closed.

If louvers become tangled or have moved out of alignment with use, re-adjustment is simple. With your hand, gently adjust the louvers so they are all facing the same direction. Make certain that the louvers are overlapping each other in the correct direction. Rotate the wand until you hear a grinding sound. Give the wand an additional gentle turn. This grinding noise comes from the louver carriers re-aligning themselves. Now rotate the wand in the opposite direction and all of the vanes will be aligned correctly.

Inside Mount Installation Video






Outside Mount Installation Video




Vertical Blind – Luxury Valance Instructions

Side Views




Top Views



Outside Mount

- The valance body fascia is cut 1" less than the exact rail width. Attach each corner to the end of the valance. Each corner extends 1 1/4" beyond valance body fascia to fit over the track. Attach the returns to the corners. The depth of the return is 6" to allow for coverage from corner to the wall. Slide the trim into the corners and returns. Use the slide the dustcover to the valance clips located on top of the headrail bracket.

Inside Mount



- The valance body fascia is cut to the exact window opening specified by customer. To install, hold the dustcover of the valance under the top frame of the window, place the headrail mounting clip under the dustcover. Screw into bracket and thru the valance dustcover.

No corners and no returns.

Trim Insertion Tip

- The rubber trim can be challenging to insert into the small corners and returns of the valance. To make this process smoother, it's recommended to slightly warm the trim with a heat source, such as a hairdryer or heat gun, for a few seconds before attempting to insert it. The heat will soften the rubber, allowing it to better conform to the tight corners and returns. Be sure to use moderate heat to prevent any damage to the trim, and work carefully to ensure a snug fit.

